

## HONDA ENGINE SPARE LIST

| Sr No.              | ITEM                                                                                | NAME                            |
|---------------------|-------------------------------------------------------------------------------------|---------------------------------|
| 1                   |   | Honda Engine<br>GX160/200/270cc |
| Air Filter Assembly |                                                                                     |                                 |
| 2                   |  | Honda GX200 Air Filter          |
| 3                   |  | Cyclonic Air Filter             |

|   |                                                                                     |                                        |
|---|-------------------------------------------------------------------------------------|----------------------------------------|
| 4 |    | Air Filter Seal                        |
| 5 |    | Nut Flange M6                          |
| 6 |  | Honda Upper Air Filter<br>Elbow Collar |
| 7 |  | Air Cleamer Elbow<br>Mounting Collar   |

|    |                                                                                     |                                   |
|----|-------------------------------------------------------------------------------------|-----------------------------------|
| 8  |    | Air Filter Noise Cover<br>Ut2 Ut3 |
| 9  |   | Air Filter Cover Ut2<br>Ut3       |
| 10 |  | Air Filter                        |
| 11 |  | Air Filter Gas Kit                |

|                |                                                                                     |                    |
|----------------|-------------------------------------------------------------------------------------|--------------------|
| 12             |    | Air Filter Gas Kit |
| Ignition Parts |                                                                                     |                    |
| 13             |   | Spark Plug         |
| 14             |  | Stop Switch        |
| 15             |  | On Off Switch      |

|    |                                                                                      |                            |
|----|--------------------------------------------------------------------------------------|----------------------------|
| 16 |     | Ignition Spark Plug Tester |
| 17 |     | Crankcase Cover Gasket     |
| 18 |   | Oil Level Switch           |
| 19 |  | Oil Alert Trigger Unit     |

|    |                                                                                     |                                       |
|----|-------------------------------------------------------------------------------------|---------------------------------------|
| 20 |    | Ignition Coil                         |
| 21 |    | Stop Switch 1 Wire                    |
| 22 |  | Stop Switch 2 Wire                    |
| 23 |  | Spark Plug Cap with Noise Suppression |

## Fuel Parts

24



Fuel Tank

26



Carbuettor Stud  
6x112mm

27




Fuel Tube 4.5mm x 1M

28



Carburettor Gasket Set  
Gc01, Gcagt,  
Gcbmt,Gcaat,Gcahk,Gcb  
nt

|    |                                                                                     |                                 |
|----|-------------------------------------------------------------------------------------|---------------------------------|
| 29 |    | Carburettor<br>Insulator Gasket |
| 30 |    | Insulator Gasket                |
| 31 |   | Choke Lever<br>Carburettor      |
| 32 |  | Fuel Tank Cap                   |

|    |                                                                                     |                         |
|----|-------------------------------------------------------------------------------------|-------------------------|
| 33 |    | Carburettor Non Genuine |
| 34 |   | Fuel Tank Filter        |
| 35 |  | Fuel Tank Neck Filter   |
| 36 |  | Fuel Cap Seal           |

|               |                                                                                     |                                                   |
|---------------|-------------------------------------------------------------------------------------|---------------------------------------------------|
| 37            |    | Fuel Tank Cap Plastic                             |
| Starter Parts |                                                                                     |                                                   |
| 38            |  | Recoil Flange Bolt M6<br>Thread x 8mm Hex<br>Head |
| 39            |  | Recoil Rope                                       |
| 40            |  | Recoil Starter Handle<br>Pack                     |

|    |                                                                                     |                              |
|----|-------------------------------------------------------------------------------------|------------------------------|
| 41 |    | Recoil Starter Plastic Pawls |
| 42 |   | Recoil Spring                |
| 43 |  | Starter Ratchet Pawl         |
| 44 |  | Pawl Return Spring           |

|               |                                                                                     |                     |
|---------------|-------------------------------------------------------------------------------------|---------------------|
| 45            |    | Plastic Pawl Set    |
| Control Parts |                                                                                     |                     |
| 46            |    | Bolt & Washer M6x20 |
| 47            |    | Governor Rod        |
| 48            |  | Flange Bolt M6x28   |
| 49            |  | Throttle Lever      |

|    |                                                                                    |                        |
|----|------------------------------------------------------------------------------------|------------------------|
| 50 |   | Throttle Return Spring |
| 51 |   | Governor Spring        |
| 52 |  | Throttle Lever         |

## Exhaust Parts

|    |                                                                                     |                     |
|----|-------------------------------------------------------------------------------------|---------------------|
| 53 |  | Exhaust Stud 8x30mm |
| 54 |  | Exhaust Gasket      |
| 55 |  | Exhaust Muffler     |

## Internal Parts

56



Inlet Valve

57



Gcarh Gcbdh Piston  
Ring Set

58



Cylinder Head Assy


59



Exhaust Valve

|    |                                                                                     |                           |
|----|-------------------------------------------------------------------------------------|---------------------------|
| 60 |    | Gcbtt Valve Stem Oil Seal |
| 61 |   | Gcarh Gcbdh Piston        |
| 62 |  | Piston Rings              |
| 63 |  | Push Rod Guide Plate      |

|    |                                                                                     |                  |
|----|-------------------------------------------------------------------------------------|------------------|
| 64 |    | Valve Rocker Arm |
| 65 |    | Piston Pin       |
| 66 |   | OHV Head Cover   |
| 67 |  | Piston Pin Cilp  |

|        |                                                                                     |                              |
|--------|-------------------------------------------------------------------------------------|------------------------------|
| 68     |    | Connecting Rod               |
| Gasket |                                                                                     |                              |
| 69     |    | Crankcase Gasket             |
| 70     |  | Engine Gasket Set            |
| 71     |  | Carburettor Insulator Gasket |

|          |                                                                                     |                       |
|----------|-------------------------------------------------------------------------------------|-----------------------|
| 72       |    | Air Filter Gasket     |
| 73       |   | Insulator Gasket      |
| 74       |   | OHV Head Cover Gasket |
| 75       |  | Exhaust Gasket        |
| Oil Seal |                                                                                     |                       |
| 76       |  | Oil Seal 30x46x8mm    |

|    |                                                                                     |                                        |
|----|-------------------------------------------------------------------------------------|----------------------------------------|
| 77 |    | <b>Oil Seal 30x46x8mm</b>              |
| 78 |    | <b>Oil Seal 30x46x8mm</b>              |
| 79 |   | <b>Oil Seal 30x46x8mm</b>              |
| 80 |  | <b>E Starter Kit<br/>Gx160/200/270</b> |
| 81 |  | <b>Piston Pin</b>                      |

|    |                                                                                     |                                              |
|----|-------------------------------------------------------------------------------------|----------------------------------------------|
| 82 |    | <b>Stud M8</b>                               |
| 83 |    | <b>Cover Asy<br/>Crankcase</b>               |
| 84 |  | <b>Crankshaft Assy<br/>Sm120</b>             |
| 85 |  | <b>Pulley Comp<br/>Starter<br/>Gx200/270</b> |

|    |                                                                                   |                                     |
|----|-----------------------------------------------------------------------------------|-------------------------------------|
| 86 |  | <b>Deflector Comp<br/>Gx160/200</b> |
| 87 |  | <b>Tube Breather<br/>Gx160 /200</b> |

**N**

**K**

